



Index

I

ndex

+Media Button 8.4
 100% and 75% (ToasterScope) 17.8
 100% Color Bars (Proc Amp) 18.12
 16:9 Height (ToasterVision) 5.6
 4 Corner Gradient 15.4
 4:3 Height (ToasterVision) 5.6
 8mm format 2.8

A

About the Manual 1.3
 About Video 101 1.4
 Access File Properties 6.5
 Accessing Your Colors 13.5
 Active Video (CG) 14.2
 Adaptor, BNC 2.16
 Add a DVE 12.3
 Add a folder to the Hotlist: 6.3
 Add overlay from context menu 8.50
 Add CD player 9.15
 Add Clips (DDR) 10.15
 Add instruments 9.15
 Add the keyed video to the background video
 in ToasterEdit 8.36
 Add, Delete, and Clone CG Pages 14.21
 Adding Clips (DDR) 10.2
 Adding Sources to the Switcher 7.6
 Adjust a box after you create it 14.7
 Adjust a circle after you create it 14.10
 Adjust Polygon after you create it 14.8
 Adjust both in and out frames (slip and
 slide): 8.19
 Adjust DVE speed 12.4
 Adjust in/out points numerically 8.26

Adjust italics (CG) 14.13
 Adjust in and out points graphically
 8.26
 Adjust only audio (for crouton with audio and
 video) 8.19
 Adjust the border (CG) 14.14
 Adjust the Shadow (CG) 14.14
 Adjust volume clip in the DDR 10.6
 Adjusting In and Out Points 8.26
 Advanced Settings (Proc Amp) 18.10
 Advancing DVEs 7.16
 Alias 6.6
 Alias for a file 6.6
 Alias for Hotlist item 6.4
 Alien 8.56, 8.57, 8.60, 14.43, 14.44, Apc.56
 Alignment (CG) 14.18
 Alpha (SX-8) 2.17
 Alpha and CG 14.11
 Alpha Channel (Color Picker) 13.2
 Always on Top 3.4
 Amplitude (Waveform Monitor) 18.13
 Amplitude, distorted (ToasterScope) 17.7
 Analog (Format) 2.8
 Animated Icons 6.8
 Animated Icons and the Keyboard 6.8
 Apply Speed to Presets 9.13
 Arc Start and End (CG) 14.28
 Arc/Line Properties 14.27
 Assignments/Shortcuts 3.11
 Attach the Bridge Card 1.11
 Attenticons 1.5
 Audience for Web Video ApB.6
 Audio (SX-8) 2.18
 Audio boost see Phantom power
 Audio Capture for the Web ApB.7
 Audio Clips (DDR) 10.8
 Audio Codecs 4.7
 Audio Connectors 2.2

Audio distortion	9.6
Audio Drive	1.9
Audio Drive Requirements	1.9
Audio Edit Properties Panel	8.44
Audio in ToasterEdit	8.43
Audio Level	4.14
Audio Mixer (Intro)	1.2
Audio Mixer and the Switcher	9.17
Audio Mixer Presets (Task)	9.16
Audio Mixer: Aux Send and Return	9.10
Audio Mixer: Aux	9.7
Audio Mixer: Channels	9.6
Audio Mixer: Cue	9.13
Audio Mixer: Follow	9.14
Audio Mixer: Input and Output	9.2
Audio Mixer: Live and Preview	9.11
Audio Mixer: Manual Control	9.9
Audio Mixer: Mono	9.8
Audio Mixer: PA Mix and SX-8 Live	9.14
Audio Mixer: Pan	9.8
Audio Mixer: Presets	9.12
Audio Mixer: Treble and Bass	9.7
Audio Mixer: Volume Unit Meters	9.6
Audio Mixer: Volume	9.9
AuraVT Documentation	1.4
Auto and S-M-F	7.10
Automatic In/Out Offset	3.15
Autosave	3.17
Aux (Audio Mixer)	9.7
Aux Return	2.20
Aux Send and Return	9.10
Aux Send	2.20
AVI Options	4.5

B

Back (File Bin)	6.2
-----------------	-----

Background (CG)	14.18
Background color and Switcher	15.5
Background, Black	7.7
Balanced and Unbalanced Input	9.4
Balanced audio	2.18
Bass	9.7
Behavior (CG)	14.15
Betacam format	2.8
Betacam, Digital format	2.8
Bevel Border	14.24
Black and White Television	18.3
Black Background	7.7
Black level (ToasterScope)	17.6
Black Level	18.13
Black Source	7.7
Blanking and Burst	17.8
Blanking Level	18.13
Blue Screens	16.6
Blue/Yellow Signal	see U Offset and U Gain
BNC connector	2.16
Border Fill (CG)	14.24
Border Properties (CG)	14.23
Border Type (CG)	14.23
Borders and Shadows in CG	14.14
Boxes in CG	14.7
Breakout Box	2.3
Breakout Box Context Menu	2.12
Breakout cable	2.1
Brightness (Proc Amp)	18.3
Burst	17.8
Burst Phase	18.14
Bus Dots	7.7
Busses (Switcher)	7.2
Butt Ending Type	14.28
Buttons, Tags, and Abbreviations	3.9
Bypass (Proc Amp)	18.6

C

- Cables for video input 2.1, 2.14-2.16
- Cache Preview Generation 3.16
- Calibrating a Signal 17.2
- Camera Remote control 11.1
- Capture and Chop 4.18
- Capture and Reset 4.18
- Capture and T.Lapse 4.19
- Capture from the External Control 11.4
- Capture Options 4.2
- Capture Panel 4.2
- Capture Resolutions 4.11
- Capture SDI input 2.22
- Capture SDI input 2.22
- Capture Video 4.16
- Cast shadow 14.25
- CD player 9.15
- CD-quality audio 9.1
- CG and alpha 14.11
- CG Interface 14.2
- CG Layout Diagram 14.17
- CG Pages 14.19
- CG Player 14.28
- CG Properties 14.21
- CG Styles 14.21
- CG Tools 14.5
- CG: Arc/Line Properties 14.27
- CG: Behavior 14.15
- CG: Border Properties 14.23
- CG: Circles, Pies, and Arcs 14.9
- CG: Cue 14.16
- CG: Direction 14.15
- CG: Fill Properties 14.25
- CG: Font and Size of Text 14.22
- CG: Go 14.16
- CG: Groups in Layout 14.19
- CG: Images 14.11
- CG: Layout Layers 14.18
- CG: Lines 14.9
- CG: Modify button 14.12
- CG: Motion 14.14
- CG: Polygons and Splines 14.8
- CG: Program Out 14.16
- CG: Safe Area 14.2
- CG: Saving and Exiting 14.4
- CG: Shadow Properties 14.24
- CG: Speed Control 14.16
- CG: Text Properties 14.21
- CG: Text 14.5
- Change in and out points for a Storyboard crouton 8.18
- Change length (ToasterEdit) 8.23
- Channel Controls (Audio Mixer) 9.7
- Channels (Color Picker) 13.3
- Channels (Switcher) 7.2
- Chapters for Panel Specifics 1.4
- Character Generator (Intro) 1.2
- Character Range 14.25
- Chop 4.15
- Chop a crouton 8.50
- Chroma Key in ToasterEdit 8.36
- Chroma Keying 16.2
- Chroma Keying and the Switcher 7.5
- Chrominance Gain (Waveform Monitor and Vectorscope) 18.15
- Chrominance Gain (Waveform Monitor) 18.14
- Chrominance Phase (Vectorscope) 18.14
- Chrominance Signal (ToasterScope) 17.9
- Cinepak Codec 4.4
- Circle Width and Height (CG) 14.28
- Circles, Pies, and Arcs in CG 14.9

Clip Start Time	8.29	Component (cable and SX-8)	2.14
Clone CG Pages	14.21	Composite (cable and SX-8)	2.16
Closing Panels	3.6	Compositing (ToasterEdit)	8.35
Closing the Color Picker	13.6	Compressed Video	1.3
Closing the DDR	10.9	Compression Formats	4.4
Codecs and Resolution (ToasterEdit)	8.54	Computer Connections	2.6
Codecs	4.4	Connect Y/C on SX-8	2.15
Codes for DVEs	12.5	Connections	2.1
Collapse a subproject	8.47	Context Menu (Keyer)	16.7
Color Bars and the VectorScope	17.9	Context Menu (Proc Amp)	18.7
Color Bars and the Waveform Monitor	17.6	Context Menu (Switcher)	7.17
Color Bars Test Signal	18.12	Context Menu (ToasterEdit)	8.48
Color Burst (Proc Amp)	18.14	Context Menu (ToasterVision)	5.4
Color Burst	17.8	Context Menu and Presets (Cross Keyer)	16.9
Color Channels	13.2	Context Menu, Breakout Box	2.12
Color Correction (ToasterEdit)	8.34	Context Menus	3.6
Color for Keying	16.4	Contrast (Proc Amp)	18.3
Color intensity <i>see</i> Saturation		Control Hints	3.8
Color Palette	13.2	Control the overall volume of the DDR	10.6
Color Picker: Alpha Channel	13.2	Copy and Paste (File Bin)	6.2
Color Picker: Channels	13.3	Copy keyframes	8.42
Color Picker: Eyedropper	13.4	Copying Keyframes	8.42
Color Picker: HSL Channels	13.3	Correct chrominance gain	18.15
Color Picker: Illegal Colors	13.4	Correct chrominance phase	18.15
Color Picker: NTSC and PAL	13.6	Crawling text (CG)	14.15
Color Picker: RGB Channels	13.3	Crawling the Lower Third on Screen	14.41
Color Picker: Spectrum	13.3	Create a background color	15.2
Color Picker: YUV Channels	13.3	Create a box (CG)	14.7
Color Reference	17.8	Create a circle (CG)	14.10
Color-code a file	6.6	Create a Custom Color Swatch	13.7
Color-code croutons	8.18	Create a line (CG)	14.9
Comments (ToasterEdit)	8.30	Create a Lower Third	14.37
Common Action Buttons (ToasterEdit)	8.7	Create a Page Build	14.45
Common Formats (Video 101)	2.8	Create a partial circle	14.10
Compatible Formats (ToasterEdit)	8.12	Create a Preset (Audio Mixer)	9.12

Create a Scroll 14.42
 Create a semi-transparent background color 15.2
 Create a single-frame crouton 8.51
 Create a subproject 8.46
 Create Swatch with Transparency 13.8
 Create a Title Page 14.30
 Create stripe set 1.9
 Create text 14.6
 Cross Keyer 16.8
 Cross Keyer Task 16.12
 Crouton Height 8.22
 Cue (Audio Mixer) 9.13
 Cue (DDR) 10.5
 Cue a Preset (Audio Mixer) 9.13
 Cue and Pause (DDR) 10.5
 Cue and the Switcher (DDR) 10.15
 Cue CG 14.16
 Cue the DDR 10.5
 Custom Color Swatch 13.7
 Cut transition *see* Take
 Cut, Copy, and Paste (File Bin) 6.2
 Cut, Copy, Paste, and Delete (ToasterEdit) 8.7

D

Daughter Card 2.8
 DDR and Audio 10.6
 DDR and bus dot 10.13
 DDR and Switcher 10.12
 DDR and ToasterEdit 10.14
 DDR and ToasterVision 10.12
 DDR Resource Usage 3.15
 DDR/Editor Preferences 3.15
 DDR: Add Clips 10.15
 DDR: Context Menu 10.12
 DDR: Cue 10.5

DDR: Deck Controls 10.3
 DDR: Loop Play Mode 10.11
 DDR: Play Modes 10.10
 DDR: Playlist Mode 10.10
 DDR: Playlist 10.2
 DDR: Recording 10.4
 DDR: Shuttle and Jog 10.4
 DDR: Timecode Display 10.11
 Deck Controls (Capture) 4.15
 Deck Controls (DDR) 10.3
 Deck Controls (External Control) 11.2
 Dedicated Drives 1.8
 Default Icons 6.9
 Default Still Length 3.15
 Defaults (Proc Amp) 18.8
 Delete CG Pages 14.21
 Delete Keyframes 8.42
 Delete sources (Switcher) 7.7
 Deleting Video Clips (DDR) 10.9
 Delta 3.18
 Deselect Cross Keyer Colors 16.10
 Desktop Caching 3.13
 Diagonal gradient 15.5
 Digital (Format) 2.8
 Digital Active Area (Video 101) 2.12
 Digital Betacam format 2.8
 Digital Inputs 2.16
 Digital Monitor (ToasterVision) 5.1
 Digital Video Effects 12.1
 Digital-8 format 2.8
 Direction (CG) 14.15
 Display Switcher Numbers inside BoB 3.17
 Dissolve (Switcher) 7.9
 Distorted amplitude (ToasterScope) 17.7
 Distorted timing (ToasterScope) 17.7
 Distortion, audio 9.6

Dither Black Background	3.17	DVE with Switcher controls	7.15
Do Not Render CG	14.15	DVE with the right mouse button	7.16
Documentation for other Applications	1.4	DVEs	1.2
Downloadable Files (Streaming)	ApB.2	DVEs and Masking (ToasterEdit)	8.23
Downstream Key (Switcher)	7.12	DVEs and the Edit Properties Panel	8.43
Downstream Key (ToasterVision)	5.4	DVEs and the Switcher	7.15
Drag in/out points (ToasterEdit)	8.23	DVEs and Transitions	12.2
Dragging Timeline Croutons	8.22	DVEs in Reverse	12.5
Dragging Video and DVE Edges	8.23	DVEs in ToasterEdit	12.6
Drill into a subproject	8.47	DVEs on the Switcher	12.3
Drive Space (Capture)	4.2	DVEs: Advancing	7.16
Drop shadow	14.24		
Drop-frame timecode	10.9		
Dropped Frames	4.13	E	
Drop-shadow (CG) see Shadow		Edit Button (ToasterEdit)	8.9
DSK	7.12	Edit Decision List	12.5
DSK (ToasterVision)	5.4	Edit Line (ToasterEdit)	8.21
DSK and background generator	15.5	Edit Proc Amp settings	2.13
DSK Shortcuts	7.14	Edit Properties panel	8.24
DSK Sources	7.12	Edit Streams	8.30
DSK: fade onto video	7.13	Editing the File Bin	6.2
DSK: semi-transparent	7.13	EDL and DVE	12.5
Duration (ToasterEdit)	8.29	Effects Bus (Switcher)	7.14
DV remote control	11.2	Elapsed Time (DDR)	10.11
DVC Pro50 format	2.8	Electrostatic discharge	2.9
DVCam format	2.8	Encoding (Streaming)	ApB.1
DVE and Auto	12.4	Ending Type (CG)	14.28
DVE and EDL	12.5	Enter Values for Custom Color	13.7
DVE and Spacebar	12.6	Exiting Video Toaster [2]	3.3
DVE directory	12.2	Expand a subproject	8.46
DVE numeric codes	12.5	Explanation of color	13.5
DVE QuickCall	12.5	External Control warning	11.2
DVE Root Path	3.16	External Control: Context Menu	11.3
DVE Root Path	3.16	External Control: Deck Controls	11.2
DVE Shortcuts	7.17	External Control: Interface	11.1
DVE Speed	12.4	External Control: Timecode	11.3
DVE Speed	7.15	Eyedropper (Color Picker)	13.4

Eyedropper tool (Keying) 16.5

F

Factory Settings (Proc Amp Advanced) 18.10

Fade semi-transparent DSK 7.13

Fade audio (ToasterEdit) 8.45

Fade DSK onto video 7.13

Fading Audio 8.44

Fast Refresh 17.3

Fielding (ToasterVision) 5.8

File Bin 1.1

File Bin 6.1

File Bin Context Menu 6.5

File Bin Options 6.2

File Bin Shortcuts 6.9

File Bin Usage 6.2

File Button (ToasterEdit) 8.6

File Formats 3.19

File Name with Extension 6.8

File Naming and File Location 4.14

File Path (Capture) 4.14

File Properties 6.5

Fill and Gradient (CG) 14.26

Fill Properties (CG) 14.25

Fill Range (CG) 14.25

Fill Rotation 14.26

Fill Type (CG) 14.26

Finish and Play 8.61

Finish the Program 9.18

floppy drive power 2.11

Follow (Audio Mixer) 9.14

Font and Size of Text 14.22

Footage for the Cross Keyer 16.10

Force Clean Exit 3.14

Foreground (CG) 14.18

Format, 8mm 2.8

Format: Betacam 2.8

Format: Digital Betacam 2.8

Format: Digital-8 2.8

Format: DVC Pro50 2.8

Format: DVCam 2.8

Format: Hi-8 2.8

Format: Mini-DV 2.8

Format: SVHS 2.8

Format: VHS 2.8

Formats 4.4

Forward (File Bin) 6.2

FourCorner Fill(CG) 14.26

Frame Rate (Streaming) ApB.8

Frames per Second (capture formats) 4.11

Full Path for File Name 6.8

G

Gain (ToasterScope) 17.7

General Buttons on the CG 14.4

General Options (Edit Properties) 8.28

Genlock (SX-8) 2.17

Genlock 3.18

Getting Files on the Server ApB.5

Getting Video on the Web ApB.5

Global Shortcuts 3.11

Go (CG) 14.16

Gradient (CG) 14.26

Gradient Backgrounds 15.3

Gradient keying *see* Linear keying

Graphics cards 1.6

Graticule 17.7

Green Screens 16.6

Grid in CG *see* Safe area

Grounding for installation 2.9

Groups in Layout (CG) 14.19

H

Hardware Breakout Box	2.3
Hardware Installation: VT Card	1.10
Hardware patch for multi cameras	7.20
Hi-8 format	2.8
High frequency noise	<i>see</i> Treble
Hiss	<i>see</i> Treble
Hold and Restore configurations	3.7
Horizontal blanking	17.8
Horizontal Gradient	15.3
Hotlist	6.3
House Sync	2.17
How to Read the Vectorscope	17.7
How to Read the Waveform Monitor	17.6
HSL Channels (Color Picker)	13.3
Hue (Color Picker)	13.3
Hue (Proc Amp)	18.4
Hum	<i>see</i> Bass

I

Icon Only	6.8
Icons, Animated	6.8
Icons, Default	6.9
IDE	1.8
IDE DMA	1.8
Images in CG	14.11
Impedance (Audio Mixer)	9.2
Importing Text (CG)	14.6
In and Out points (DDR)	10.7
In and Out Points (ToasterEdit)	8.25
In/Out Point Display Style	3.15
In/Out Point Scaling Factor Display	3.15
Indeo Codec	4.4
Inherit (ToasterEdit)	8.49
Inherit settings from a crouton	8.49

Inherit settings from crouton (keyboard shortcut)	8.49
Input and Output (Audio Mixer)	9.2
Input and Output (Capture)	4.12
Input from CD player	9.15
Input from musical instruments	9.15
Inputs and Outputs	2.13
Install the daughter card	2.9
Installation: Video Toaster Card	1.10
Installation: Software	1.12
Installing the SDI card	2.28
Intensity (Color)	<i>see</i> Saturation
Interlaced formats	4.11
Internet Streaming	7.20
Into Sub-Project	8.50
IRE	17.6
Italics and Rotation of Text	14.22
Italics for CG Text	14.13

J

Joint Type (CG)	14.27
Justification (CG)	14.6

K

Key (ToasterVision)	5.3
Key Bus	7.4
Key bus and the Keyer	7.5
Key bus and the Keyer with Unlock Key	7.5
Keyboard and Animated Icons	6.8
Keyer Presets	16.7
Keyer: Color	16.4
Keyer: Context Menu	16.7
Keyer: Eyedropper tool	16.5
Keyer: Interface	16.2
Keyer: Luma Keying	16.1
Keyer: Recall and store presets	16.7

Keyer: Smooth 16.6
 Keyer: Tolerance 16.5
 Keyers (Intro) 1.2
 Keyframe audio volume 8.45
 Keyframe Search 8.42
 Keyframing (ToasterEdit) 8.40
 Keyframing Audio 8.45
 Keying and CG 16.7
 Keying and shadows 16.3
 Keying for titles 16.3

L

Large Icons 6.7
 Launch DSK 7.13
 Layering Audio 8.46
 Layout Alignment and Spacing (CG) 14.18
 Layout Layers (CG) 14.18
 Layout Management Options (File Bin) 6.5
 Layout Tab (CG) 14.17
 LEDs (DDR) 10.4
 LEDs (SX-8) 2.4
 Left and right clicking 1.5
 Levels of gray *see* Contrast
 Lightness (Color Picker) 13.3
 LightWave Documentation 1.4
 Line and Border Thickness (CG) 14.28
 Linear Keying 16.3
 Linear Luma 16.3
 Lines in CG 14.9
 Ling Fill (CG) 14.26
 Live and Preview (Audio Mixer) 9.11
 Live Encoding ApB.2
 Live Internet Streaming 7.20
 Live on Switcher 7.3
 Live Switching 7.20
 Load a DVE 12.3

Load an image (CG) 14.11
 Load an undo-redo stack 8.8
 Load DVEs into the Effects bus 7.14
 Loading and Saving configurations 3.7
 Locating DVEs 12.2
 Lock (CG) 14.23
 Lock A/V Streams 8.29
 Lock main menu 3.2
 Loop (SX-8) 2.17
 Loop Play Mode (DDR) 10.11
 Looping (ToasterEdit) 8.12
 Looping Text (CG) 14.15
 Low frequency noise *see* Bass
 Luma Key and Position (Edit Properties) 8.58
 Luma Keying 16.1
 Luma Keying and the Switcher 7.5
 Luma White and Luma Black 16.2
 Luminance Signal 17.6

M

Main (ToasterVision) 5.4
 Main Bus 7.3
 Main Menu 3.2
 Main Menu Lock 3.2
 Make multi-cam style edit 8.24
 Manual Control (Audio Mixer) 9.9
 Manual Conventions 1.5
 Manual Organization 1.4
 Manually Setting Keyframes 8.41
 Maximize a Pane 8.2
 Maximize 3.3
 Microphone inputs 2.18
 Microphone phantom power 2.18
 Microphone/XLR Balanced Input 9.2
 Microsoft Codecs 4.4
 Mini-DV format 2.8

Minimize panels 3.3
Minimize Video Toaster 3.3
Miter Border 14.24
Modify button (CG) 14.12
Module Autosave 3.17
Module Configurations 3.6
Money Shot 8.27
Monitoring a Signal 17.2
Monitoring the Chrominance Signal 17.9
Monitoring the Luminance Signal 17.6
Mono 9.8
Motion Builder 8.31
Motion for CG 14.14
Motion Removal When Jogging 3.16
Mouse clicks 1.5
Mouse Inside ToasterVision 3.17
Move (CG) 14.12
Move an item (CG) 14.12
Move and Make Subproject on Storyboard 8.56
Move Storyboard croutons 8.16
Moving and Cloning Clips (DDR) 10.8
Moving around the Storyboard 8.16
Moving Panels 3.8
Moving Sources on Switcher 7.8
Multi-cam Style Edits 8.24
Multiple Cameras and Switcher 7.20
Multiple DDR labels 10.13
Multiple Desktops 3.9
Multiple Desktops: Shortcuts 3.9
Multiple monitor 3.10
Multiple User Configurations 3.11
Musical instruments 9.15
Mute Channels 9.9

N

Name Only 6.8
Naming Clips from Edit panel 8.25
Navigate CG Pages 14.21
Navigating the File Bin 6.2
New Folder 6.4
New Modules 3.18
NTFS file system 1.7
NTSC and PAL (Color Picker) 13.6
Numbered Tags (DDR) 10.13
Numbers inside BoB 3.17
Numeric codes for DVEs 12.5
Numeric Values for Color 13.7

O

Offset (ToasterEdit) 8.28
On Air Stream 3.4
Open a recent ToasterEdit project 8.5
Organization and Features 3.8
Original Settings (Proc Amp Advanced) 18.10
Other Applications and Documentation 1.4
Other Modules 3.17
Output for CG 14.16
Output Mode (Preference) 3.14
Output Pedestal Mode (Preference) 3.14
Overlay 8.29
Overlay (ToasterEdit) 8.49
Overlay a crouton 8.49
Overlay positioned video 8.40
Over-modulation 9.6
Overscan (CG) 14.2
Oversize image (CG) 14.4

P

- PA Mix (SX-8) 2.20
- PA Mix and SX-8 Live 9.14
- Pacifica RK95 Keyer 16.2
- Pad (Audio Mixer) 9.3
- Padlock 3.2
- Pages and Layout in CG 14.17
- Pages Tab (CG) 14.19
- Paint (Cross Keyer) 16.9
- Palette of Color Swatches 13.2
- Pan (Audio Mixer) 9.8
- Pan a zoomed image 8.32
- Pan and hold an image 8.32
- Pan image from left to right 8.32
- Pan the Time Bar 8.20
- Panel States 3.7
- Panels and Skins 3.4
- Partition size 1.7
- Paste (File Bin) 6.2
- Paste into a subproject 8.50
- Pasteboard (CG) 14.2
- Patch computer-generated input to Audio Mixer 9.5
- Patch and test input without Switcher 2.13
- Patch bays (Switcher) 7.2
- Patch hardware for multiple cameras 7.20
- Patch Points for Audio Files 9.5
- Patch to Switcher 7.6
- Pause and Cue (DDR) 10.5
- Pause When Recording Ends 4.14
- PC Monitor Refresh Rate 1.12
- PCI Bus Speed (Preference) 3.14
- Peak-to-Peak 17.6
- Perfect Signal 18.12
- Perform slip and slide on audio only 8.19
- Phantom power 2.18
- Phantom power 9.3
- Phase (ToasterScope) 17.7
- Phase control *see* Hue (Proc Amp)
- Pick Color for Keying 16.4
- Pick Color/Eyedropper 13.4
- Picture Size (Streaming) ApB.8
- Play from the File Bin 6.9
- Playback a slow motion preview 8.10
- Playing Clips (DDR) 10.3
- Playlist (DDR) 10.2
- Playlist Mode (DDR) 10.10
- Polygons and Splines in CG 14.8
- Position Indicators (DDR) 10.8
- Positioning (ToasterEdit) 8.38
- Post-fader 9.10
- Power for the daughter card 2.10
- Pre-fader 9.10
- Preference: DDR Resource Usage 3.15
- Preference: DDR/Editor Preferences 3.15
- Preference: Default Still Length 3.15
- Preference: Delta 3.18
- Preference: Desktop Caching 3.13
- Preference: Display Switcher Numbers inside BoB 3.17
- Preference: Dither Black Background 3.17
- Preference: Genlock 3.18
- Preference: Motion Removal When Jogging 3.16
- Preference: Mouse Inside ToasterVision 3.17
- Preference: Output Mode 3.14
- Preference: Output Pedestal Mode 3.14
- Preference: PCI Bus Speed 3.14
- Preference: Preview generation 3.16
- Preference: Preview generation 3.16
- Preference: Record Naming 3.16

Preference: Record Naming	3.16
Preference: Record Write and File Errors	3.17
Preference: Rollover Animated Previews	3.18
Preference: Storyboard Insertion Mode	3.16
Preference: TE Project Start Mode	3.19
Preferences	3.13
Preliminaries	8.56
Preset Speed (Audio Mixer)	9.13
Presets (Audio Mixer)	9.12
Presets (Keyer)	16.7
Presets (Proc Amp)	18.9
Preview (Audio Mixer)	9.11
Preview (ToasterVision)	5.4
Preview Bus	7.3
Preview DVEs	12.2
Preview generation (Preference)	3.16
Preview multiple cameras	7.20
Preview the in and out points for a Storyboard crouton	8.18
Previewing DVEs	12.2
Previews of CG Styles	14.21
Pro Proc Amp	18.3
Proc Amp and Color Bars	18.16
Proc Amp and Switcher	18.7
Proc Amp and Tinted People	18.17
Proc Amp: Advanced Settings	18.10
Proc Amp: Brightness	18.3
Proc Amp: Bypass	18.6
Proc Amp: Context Menu	18.7
Proc Amp: Contrast	18.3
Proc Amp: Defaults	18.8
Proc Amp: Hue	18.4
Proc Amp: Interface	18.2
Proc Amp: Presets	18.9
Proc Amp: Saturation	18.4

Proc Amp: Skins	18.2
Proc Amp: Tag Menu	18.11
Proc Amp: Track Preview	18.7
Proc Amp: U Gain	18.6
Proc Amp: U Offset	18.5
Proc Amp: V Gain	18.6
Proc Amp: V Offset	18.5
Proc Amp and ToasterScope	18.12
Program Out (CG)	14.16
Progressive formats	4.11
Project Mode (DDR)	10.10
Projecting Ending Type	14.28
Projects and Sub-projects	8.3
Properties (CG)	14.21

Q

Quick Tour of Software	1.3
QuickCall (DVE)	12.5
QuickPlayer	6.9

R

Rainbow Fill(CG)	14.26
RAM requirements	1.6
Range Between Two Colors	13.8
Range Between Two Colors	13.8
Range from Dark to Light	13.8
Range of Colors in the Palette	13.8
Razor at Edit Line	8.50
RBG Waveform	17.5
RCA Stereo Input on the SX-8	9.4
RCA Unbalanced Inputs/Outputs	2.19
Recall a Preset (Audio Mixer)	9.12
Recall a preset (Keyer)	16.7
Recall a preset (Proc Amp)	18.9
Record	4.14
Record a Still Playlist (DDR)	10.16
Record Naming (Preference)	3.16

- Record with the External Control 11.4
 - Record Write and File Errors (Preference) 3.17
 - Recording (DDR) 10.4
 - Red/Green Signal *see* V Offset and V Gain
 - Reduce Motion (Streaming) ApB.8
 - Refresh (ToasterScope) 17.3
 - Remaining Time (DDR) 10.11
 - Remote Control for VTR 11.1
 - Remove a folder from the Hotlist 6.4
 - Remove Inactive Areas 8.52
 - Remove inputs (Switcher) 7.18
 - Remove tint 3.6
 - Rename a folder 6.6
 - Render Direction and Speed 8.54
 - Render from the File Bin 6.7
 - Render from the File Bin 8.55
 - Render Name and Location 8.54
 - Render Options (ToasterEdit) 8.53
 - Render Streams (ToasterEdit) 8.54
 - Repair video signal 18.1
 - Repeat (Switcher) 7.10
 - Replace a DVE 12.3
 - Reset (Capture) 4.15
 - Resolutions (Capture) 4.11
 - Resource Usage (DDR) 10.4
 - Restore Bypass Settings (Proc Amp) 18.8
 - Restore configurations 3.7
 - Restore Factory Settings (Proc Amp) 18.8
 - Reverse (Switcher) 7.10
 - Reverse (ToasterEdit) 8.29
 - Reverse DVE 12.5
 - Rewind\Fast Forward (ToasterEdit) 8.10
 - Rewind\Fast Forward (DDR) 10.4
 - RGB Channels (Color Picker) 13.3
 - Right and left clicking 1.5
 - Right mouse button and DVE (Switcher) 7.16
 - Right-click for custom color 13.7
 - Ripple Mode 8.27
 - Rollover Animated Previews (Preference) 3.18
 - Rotate (CG) 14.12
 - Rotate an item (CG) 14.13
 - Rotation, Fill 14.26
 - Round Border 14.23
 - Round Ending Type 14.28
 - Round Fill (CG) 14.26
 - RS422 remote control 11.1
 - RTV 4.4
- ## S
- Safe Area (CG) 14.2
 - Safe Area (ToasterVision) 5.3
 - Saturation (Color Picker) 13.3
 - Saturation (Proc Amp) 18.4
 - Save a proc amp setting 18.9
 - Save a ToasterEdit project 8.5
 - Save CG Pages 14.21
 - Save configuration for Video Toaster desktop 3.11
 - Save Proc Amp Configuration 18.9
 - Saving and Exiting the CG 14.4
 - Saving configurations 3.7
 - Saving Palettes 13.5
 - Scale (CG) 14.12
 - Scale an item (CG) 14.12
 - Scaling of Performance 1.10
 - Scrollbars and Scrolling Action 3.8
 - Scrolling text (CG) 14.15
 - Scrubbing Playback 8.11
 - SCSI 1.8
 - SDI Card 2.22

SDI Devices	2.23	Skins for ToasterVision	5.7
SDI Devices and Inputs (Video 101)	2.23	Skins: Switcher	7.2
SDI input, capture	2.22	Slim ToasterVision	5.7
SDI Inputs	2.23	Slow Refresh	17.3
SDI Signal	2.23	Small Icons	6.7
Select component input (Virtual BoB)	2.14	S-M-F	7.10
Select a composite input	2.14	Smooth (Cross Keyer)	16.10
Select a DVE	12.4	Smooth (Keyer)	16.6
Select a Swatch for Custom Color	13.7	Smooth Scroll Windows	3.19
Select a Y/C input (Virtual BoB)	2.14	Soft shadow	14.25
Select Color for Keying	16.4	Software Installation	1.12
Select Cross Keyer Colors	16.9	Solid Background	15.2
Select multiple sources (Switcher)	7.8	Solid Fill (CG)	14.26
Selecting Multiple Sources on Switcher	7.8	Spacebar and DVE	12.6
Selection Mode (DDR)	10.10	Spacing (CG)	14.18
Selection shortcuts	3.11	Specifications:	1.6
Sensitivity, audio <i>see</i> Pad		Spectrum (Color Picker)	13.3
Serial (SX-8)	2.21	Speed (CG)	14.16
Serial Digital Interface	2.22	Speed (DVE)	12.4
Server (Streaming)	ApB.5 ApB.5	Speed (ToasterEdit)	8.29
Set keyframes for position	8.41	Speed Gauge (Effects Bus)	7.16
Set keyframes in ToasterEdit	8.40	Speed Gauge (Switcher)	7.11
Set Up Audio Mixer and Switcher	9.16	Speed Proc Amp	18.3
Set up the Preferences Panel	3.22	Speed Razor Documentation	1.4
Shadow Offset (CG)	14.25	Stacking and Stretching Panels	3.8
Shadow Properties (CG)	14.24	Start with a Clear Desktop	3.2
Shadow Type (CG)	14.24	Starting Video Toaster	3.2
Shortcuts	3.11	Stereo inputs	2.18-2.19
Shortcuts for Multiple Desktops	3.10	Stop When Frames Drop	4.13
Show Full Path	6.8	Store a preset (Keyer)	16.7
Shuttle and Jog (DDR)	10.4	Store a preset (Proc Amp)	18.9
Shuttle and Jog (ToasterEdit)	8.10	Store as Bypass Settings (Proc Amp)	18.8
Size and position video	8.38	Storyboard and DVEs	8.19
Size of Text	14.22	Storyboard Croutons	8.17
Sizes for ToasterVision	5.6	Storyboard Croutons and In/Out Points	8.18
Skin groups	3.4		
Skins	3.4		

- Storyboard Insertion Mode (Preference) 3.16
 - Storyboard Track Editing (Preference) 3.19
 - Stream button 3.4
 - Streaming 7.20
 - Streaming Media (Intro) 1.3
 - Stretching Panels 3.8
 - String Range 14.25
 - Stripe set 1.9
 - Styles (CG) 14.21
 - SubProjects 8.46
 - SubProjects in the Storyboard 8.46
 - SubProjects in the Timeline 8.48
 - SVHS format 2.8
 - Swatch with Transparency 13.8
 - Switch with Auto, T-bar, and Take 7.23
 - Switch without the Switcher (Virtual BoB) 2.28
 - Switcher (Intro) 1.2
 - Switcher and background 15.5
 - Switcher and Live Internet Streaming 7.20
 - Switcher and ToasterVision 7.1
 - Switcher Context Menu 7.17
 - Switcher Interface 7.2
 - Switcher Options (Audio Mixer) 9.13
 - Switcher: Auto and S-M-F 7.10
 - Switcher: Black Source 7.7
 - Switcher: Bus Dots 7.7
 - Switcher: Busses 7.2
 - Switcher: Channels 7.2
 - Switcher: Context Menu 7.17
 - Switcher: Delete sources 7.7
 - Switcher: Dissolve 7.9
 - Switcher: DSK 7.12
 - Switcher: Effects Bus 7.14
 - Switcher: Key Bus 7.4
 - Switcher: Main Bus 7.3
 - Switcher: Moving Sources 7.8
 - Switcher: New module preference 7.6
 - Switcher: Preview Bus 7.3
 - Switcher: Repeat 7.10
 - Switcher: Reverse 7.10
 - Switcher: Selecting Multiple Sources 7.8
 - Switcher: Skins 7.2
 - Switcher: Speed Gauge 7.11
 - Switcher: Take 7.11
 - Switcher: T-bar 7.9
 - Switcher: Transitions 7.9
 - Switcher: Unlock Key 7.4
 - Switcher: Warning symbol 7.6
 - Switching and DSK 7.23
 - Switching and DVEs 7.24
 - SX-8 BoB Preferences 3.18
 - SX-8 Breakout Box 2.3
 - SX-8 Breakout Box (Intro) 1.1
 - SX-8 Live button 9.14
 - SX-8 Live button 2.20
 - Sync 17.8
 - System Preferences 3.13
 - System Requirements 1.6
 - System Specifications 1.6
- ## T
- Tag Menu (Proc Amp) 18.11
 - Tag Numbering (DDR) 10.13
 - Take 7.11
 - Tally/GPI 2.22
 - Task: Add Microphone to Breakout Box 2.25
 - Task: Add and Organize Inputs on the Switcher 7.22
 - Task: Add Clips (DDR) 10.15
 - Task: Add Component Video to the Breakout Box 2.25

Task: Add Composite Video to the Breakout Box	2.24	Task: Enter Values to Create a Custom Color	13.7
Task: Add S-video to the Breakout Box	2.24	Task: External Control	11.4
Task: Add the Breakout Box to the Video Toaster Card	2.24	Task: File Bin Interface	6.10
Task: Add Unbalanced Audio to the Breakout Box	2.26	Task: Finish and Play (ToasterEdit)	8.61
Task: Audio Mixer	9.16	Task: Finish the Program (Audio Mixer)	9.18
Task: Audio Mixer and the Switcher	9.17	Task: Get Acquainted with the Interface	3.21
Task: Audio Mixer Presets	9.16	Task: Keying	16.11
Task: Background Generator	15.6	Task: Make a Background	15.6
Task: BG on the Switcher	15.6	Task: Move Files, Create a New Folder, and Hotlist	6.10
Task: Browse to Files	6.10	Task: Pacifica Keyer	16.11
Task: Browse to Files	6.10	Task: Proc Amp and Color Bars	18.16
Task: Capture and Chop	4.18	Task: Proc Amp and Tinted People	18.17
Task: Capture and Reset	4.18	Task: Processing Amplifier	18.16
Task: Capture and T.Lapse	4.19	Task: Range Between Two Colors	13.8
Task: Capture from the External Control	11.4	Task: Range of Colors from Dark to Light	13.8
Task: Capture Panel	4.16	Task: Range of Colors in the Palette	13.8
Task: Capture Uncompressed Video	4.16	Task: Record a Still Playlist	10.16
Task: Character Generator	14.30	Task: Record a Still Playlist	10.16
Task: Color Picker	13.7	Task: Record with the External Control	11.4
Task: Crawling the Lower Third on Screen	14.41	Task: Right-click to Create a Custom Color	13.7
Task: Create a Custom Color Swatch	13.7	Task: Select a Swatch and Create a Custom Color	13.7
Task: Create a Lower Third	14.37	Task: Set up Capture from the Switcher	7.21
Task: Create a Page Build	14.45	Task: Set Up the Audio Mixer and Switcher	9.16
Task: Create a Scroll	14.42	Task: Set up the Preferences Panel	3.22
Task: Create a Swatch with Transparency	13.8	Task: Switcher	7.21
Task: Create a Title Page	14.30	Task: Switching and DSK	7.23
Task: Cue and the Switcher	10.15	Task: Switching and DVEs	7.24
Task: Digital Disk Recorder	10.15	Task: SX-8 Breakout Box	2.24
Task: Ending with CG (Switcher)	7.25		

Task: ToasterEdit	8.56	
Task: ToasterVision	5.9	
Task: Video Toaster Desktop	3.1	
Tasks for a Quick Tour of the Software	1.3	
T-bar and Transitions	7.9	
T-bar Options	7.9	
TE Project Start Mode (Preference)	3.19	
Test Signal Generator	17.2	
Text and the Keyboard (CG)	14.6	
Text Color (CG)	14.23	
Text Direction (CG)	14.22	
Text Formatting for Manual	1.5	
Text in CG	14.5	
Text justification (CG)	14.6	
Text Properties (CG)	14.21	
Texture and Images as Fill (CG)	14.27	
Texture Fill (CG)	14.26	
Thumbnail (CG)	14.19	
Time (CG)	14.16	
Time elapsed (DDR)	10.11	
Time Lapse	4.13, 4.19	
Time Limits	4.12	
Time remaining (DDR)	10.11	
Timecode	10.9	
Timecode	8.12	
Timecode (External Control)	11.3	
Timecode Display	4.3	
Timecode Display (DDR)	10.11	
Timecode Mode (DDR)	10.11	
Timed (Capture)	4.12	
Timeline Croutons	8.21	
Timeline Layout	8.20	
Timeline Time Bar	8.19	
Timing, distorted (ToasterScope)	17.7	
Tint a panel	3.5	
Tint Video Toaster desktop:	3.6	
Tinting Panels	3.5	
Tinting the BG	15.5	
Tinting the Desktop	3.5	
Tinting with the Color Picker	13.6	
To use Smooth and Tolerance for the best results in keying	16.7	
Toaster In (Audio Mixer)	9.11	
Toaster Out and Master Signal (Audio Mixer)	9.14	
ToasterEdit (Intro)	1.2	
ToasterEdit and DDR Cache	3.19	
ToasterEdit and DVEs	8.14	
ToasterEdit Croutons	8.13	
ToasterEdit File Bin	8.3	
ToasterEdit Interface	8.1	
ToasterEdit Storyboard	8.16	
ToasterEdit Timeline	8.19	
ToasterEdit: Audio	8.43	
ToasterEdit: Color Correction	8.34	
ToasterEdit: Comments	8.30	
ToasterEdit: Compositing	8.35	
ToasterEdit: Duration	8.29	
ToasterEdit: Edit Button	8.9	
ToasterEdit: Edit Line	8.21	
ToasterEdit: Inherit	8.49	
ToasterEdit: Keyframing	8.40	
ToasterEdit: Looping	8.12	
ToasterEdit: Motion Builder	8.31	
ToasterEdit: Offset	8.28	
ToasterEdit: Overlay	8.49	
ToasterEdit: Positioning	8.38	
ToasterEdit: Render Options	8.53	
ToasterEdit: Reverse	8.29	
ToasterEdit: Ripple Mode	8.27	
ToasterEdit: Shuttle and Jog	8.10	
ToasterEdit: Speed	8.29	
ToasterEdit: SubProjects	8.46	
ToasterEdit: Timecode (ToasterEdit)	8.12	

ToasterEdit: Timeline Layout	8.20
ToasterScope (Intro)	1.3
ToasterScope Interface	17.3
ToasterScope: Refresh	17.3
ToasterVision	5.1
ToasterVision and Panels without Switcher	5.9
ToasterVision and the Switcher	5.10
ToasterVision Aspect Ratio	3.18
ToasterVision Context Menu	5.4
ToasterVision Controls	5.2
Toggle	3.3
Tolerance (Cross Keyer)	16.10
Tolerance (Keyer)	16.5
Tools for CG	14.5
Total and Remaining Timecode	8.12
Trace	17.6
Track (ToasterEdit)	8.11
Track Preview (Proc Amp)	18.7
Trans Options (ToasterEdit)	8.10
Transforming CG Elements	14.12
Transitions (Switcher)	7.9
Transitions and DVEs	12.2
Transparency (Color Picker)	13.2
Transparency in CG <i>see</i> Alpha	
Transparent background color	15.2
Transparent DSK	7.13
Transparent Swatch	13.8
Treble and Bass	9.7
Trim Clips (DDR)	10.15
Trimming Audio Clips (DDR)	10.8
Trimming DDR Clips	10.7
TVision and CG	14.3
Tweak the Audio (ToasterEdit)	8.60

U

U Gain (Proc Amp)	18.6
U Offset (Proc Amp)	18.5
UltraThin ToasterVision	5.7
Unavailable source on Switcher	7.6
Unbalanced Audio	2.19
Uncompressed Video (Intro)	1.3
Underscan (ToasterVision)	5.3
Understanding Proc Amp	18.2
Undo and Redo (ToasterEdit)	8.8
Unlock Key (Switcher)	7.4
Use a loaded image	14.30
User Configurations	3.11
Using the Background Generator	15.5
Using the Switcher	7.11

V

V Gain (Proc Amp)	18.6
V Offset (Proc Amp)	18.5
Variables for Web Video	ApB.7
VCR Controls (DDR)	10.3
VCR controls (External control)	11.2
VE RT Engine	3.18
Vectorscope	17.7
Verify Monitor Refresh Rate	1.12
Vertical blanking	17.8
Vertical Gradient	15.4
VHS format	2.8
Video 101 (About)	1.4
Video 101: Balanced and Unbalanced Input	9.4
Video 101: Blanking and Burst	17.8
Video 101: Blue Screens	16.6
Video 101: Common Formats	2.8
Video 101: Digital Active Area	2.12
Video 101: How to Read the Vectorscope	17.7

Video 101: How to Read the Waveform Monitor 17.6
 Video 101: SDI Devices and Inputs 2.23
 Video 101: Sweetening 8.45
 Video 101: Timecode 10.9
 Video 101: Video Codecs 4.4
 Video 101: What is color? 13.5
 Video and Audio Capture 4.12
 Video and Audio Codec combination table 4.10
 Video Cables 2.2
 Video Codecs 4.4
 Video Combinations 2.16
 Video Drive 1.8
 Video Drive Space Requirements 1.7
 Video Mode 3.14
 Video on the Web (Streaming) ApB.5
 Video Storage Requirements 1.7
 Video Toaster [2] Features 1.1
 Video Toaster Card Input/Output 2.1
 Video Toaster Desktop (Task) 3.1
 View Modes for File Bin 6.7
 Viewing Options for ToasterVision 5.3
 Virtual Breakout Box 2.11
 Voltage (Audio Mixer) 9.2
 Volume (Audio Mixer) 9.9
 Volume (DDR) 10.6
 Volume Unit Meters (Audio Mixer) 9.6
 Volume Units Meter (Capture) 4.3
 VT 1,2 (SX-8) 2.6
 VT 3, 4, and 5 (SX-8) 2.7
 VT Audio (SX-8) 2.6
 VTR (SX-8) 2.21
 VTR Controls (ToasterEdit) 8.9
 VTR Options and Modes 8.11
 VTR Remote control 11.1

W

Warning (External control) 11.2
 Warning symbol (Switcher) 7.6
 Waveform 17.3
 Waveform black level 17.6
 What is color? 13.5
 White Level 18.13
 Width and Height of Text (CG) 14.23
 Window Always on Top 3.4
 Window Placement 3.4
 Windows Media Encoder 4.4
 Windows Media Encoder File Path 3.17
 WMV 4.4
 Work on the Timeline 8.57
 Working with Equipment (Audio Mixer) 9.15
 Working with the Background Generator 15.2
 Working with the Color Picker 13.1
 Working with the Cross Keyer 16.9
 Working with the DDR 10.2
 Working with ToasterEdit 8.5

X

XLR Inputs 2.18
 XLR Outputs 2.18

Y

Y/C (cable and SX-8) 2.15
 YC Waveform 17.5
 YUV and RBG Waveform 17.5
 YUV Channels (Color Picker) 13.3

Z

Zoom in and out of Time Bar 8.20
 Zoom in, hold, then pan the image 8.32
 Zoom out as you pan 8.32
 Zoom out of an image 8.32

