



Video Toaster [2]

This publication, or parts thereof, may not be reproduced in any form, by any method, for any purpose without prior written consent of NewTek.

© 2001 NewTek. All rights reserved.

NewTek
5131 Beckwith Blvd.
San Antonio, TX 78249

ii VIDEO TOASTER [2]

Software License and Limited Warranty

PLEASE READ CAREFULLY BEFORE INSTALLING THIS SOFTWARE. BY INSTALLING THIS SOFTWARE, YOU AGREE TO BECOME BOUND BY THE TERMS OF THIS LICENSE. IF YOU DO NOT AGREE TO THE TERMS OF THIS LICENSE, RETURN THIS PACKAGE TO THE PLACE WHERE YOU OBTAINED IT WITHIN 15 DAYS FOR A FULL REFUND.

1. Grant of License

The enclosed computer program(s) (the "Software") is licensed, not sold, to you by NewTek for use only under the terms of this License, and NewTek reserves any rights not expressly granted to you. You own the disk(s) on which the Software is recorded or fixed, but the Software is owned by NewTek or its suppliers and is protected by United States copyright laws and international treaty provisions.

The copyright restrictions of this license extend to any further updates, software patches, or bug fixes made available to you by Newtek, whether distributed by floppy disc, CD ROM, or in an electronic format via BBS, ftp, e-mail, etc.

This License allows you to use one copy of the Software on a single computer at a time. To "use" the Software means that the Software is either loaded in the temporary memory (i.e., RAM) of a computer, or installed on the permanent memory of a computer (i.e., hard disk, CD ROM, etc.).

You may use at one time as many copies of the Software as you have licenses for. You may install the Software on a common storage device shared by multiple computers, provided that if you have more computers having access to the common storage device than the number of licensed copies of the Software, you must have some software mechanism which locks out any concurrent user in excess of the number of licensed copies of the Software (an additional license is not needed for the one copy of Software stored on the common storage device accessed by multiple computers).

You may make one copy of the Software in machine readable form solely for backup purposes. The Software is protected by copyright law. As an express condition of this License, you must reproduce on the backup copy the NewTek copyright notice in the following format "© 1999 NewTek"

You may permanently transfer all your rights under this License to another party by providing such party all copies of the Software licensed under this License together with a copy of this License and all written materials accompanying the Software, provided that the other party reads and agrees to accept the terms and conditions of this License.

2. Restrictions

The Software contains trade secrets in its human perceivable form and, to protect them, YOU MAY NOT REVERSE ENGINEER, DECOMPILE, DISASSEMBLE, OTHERWISE REDUCE THE SOFTWARE TO ANY HUMAN

PERCEIVABLE FORM. YOU MAY NOT MODIFY, ADAPT, TRANSLATE, RENT, LEASE, LOAN, RESELL FOR PROFIT, OR CREATE DERIVATIVE WORKS BASED UPON THE SOFTWARE OR ANY PART THEREOF.

3. Termination

This License is effective until terminated. This License will terminate immediately without notice from NewTek or judicial resolution if you fail to comply with any provision of this License. Upon such termination you must destroy the Software, all accompanying written materials and all copies thereof. You may also terminate this License at any time by destroying the Software, all accompanying written materials and all copies thereof.

4. Export Law Assurances

You agree that neither the Software nor any direct product thereof is being or will be shipped, transferred or re-exported, directly or indirectly, into any country prohibited by the United States Export Administration Act and the regulations thereunder or will be used for any purpose prohibited by the Act.

5. Limited Warranty and Disclaimer, Limitation of Remedies and Damages.

YOU ACKNOWLEDGE THAT THE SOFTWARE MAY NOT SATISFY ALL YOUR REQUIREMENTS OR BE FREE FROM DEFECTS. NEWTEK WARRANTS THE MEDIA ON WHICH THE SOFTWARE IS RECORDED TO BE FREE FROM DEFECTS IN MATERIALS AND WORKMANSHIP UNDER NORMAL USE FOR 90 DAYS FROM PURCHASE, BUT THE SOFTWARE AND ACCOMPANYING WRITTEN MATERIALS ARE LICENSED "AS IS." ALL IMPLIED WARRANTIES AND CONDITIONS (INCLUDING ANY IMPLIED WARRANTY OF MERCHANTABILITY OR FITNESS FOR A PARTICULAR PURPOSE) ARE DISCLAIMED AS TO THE SOFTWARE AND ACCOMPANYING WRITTEN MATERIALS AND LIMITED TO 90 DAYS AS TO THE MEDIA. YOUR EXCLUSIVE REMEDY FOR BREACH OF WARRANTY WILL BE THE REPLACEMENT OF THE MEDIA OR REFUND OF THE PURCHASE PRICE. IN NO EVENT WILL NEWTEK OR ITS DEVELOPERS, DIRECTORS, OFFICERS, EMPLOYEES OR AFFILIATES BE LIABLE TO YOU FOR ANY CONSEQUENTIAL, INCIDENTAL OR INDIRECT DAMAGES (INCLUDING DAMAGES FOR LOSS OF BUSINESS PROFITS, BUSINESS INTERRUPTION, LOSS OF BUSINESS INFORMATION, AND THE LIKE), WHETHER FORESEEABLE OR UNFORESEEABLE, ARISING OUT OF THE USE OR INABILITY TO USE THE SOFTWARE OR ACCOMPANYING WRITTEN MATERIALS, REGARDLESS OF THE BASIS OF THE CLAIM AND EVEN IF NEWTEK OR AN AUTHORIZED NEWTEK REPRESENTATIVE HAS BEEN ADVISED OF THE POSSIBILITY OF SUCH DAMAGES.

The above limitations will not apply in case of personal injury only where and to the extent that applicable law requires such liability. Because some jurisdictions do not allow the exclusion or limitation of implied warranties or liability for consequential or incidental damages, the above limitations may not apply to you.

6. General

This License will be construed under the laws of the State of Texas, except for that body of law dealing with conflicts of law. If any provision of this License shall be held by a court of competent jurisdiction to be contrary to law, that provision will be enforced to the maximum extent permissible, and the remaining provisions of this License will remain in full force and effect. If you are a US Government end-user, this License of the Software conveys only "RESTRICTED RIGHTS," and its use, disclosure, and duplication are subject to Federal Acquisition Regulations, 52.227-7013 (c)(1)(ii). (See the US Government Restricted provision below.)

7. Trademarks

Video Toaster, LightWave, LightWave VT, LightWave 3D, LightWave, Aura VT, and Aura are trademarks of NewTek. Speed Razor is a trademark of in-sync corporation. All other brand names, product names, or trademarks belong to their respective holders.

8. US Government Restricted Provision

If this Software was acquired by or on behalf of a unit or agency of the United States Government this provision applies. This Software:

- (a) Was developed at private expense, and no part of it was developed with government funds,
- (b) Is a trade secret of NewTek for all purposes of the Freedom of Information Act,
- (c) Is "commercial computer software" subject to limited utilization as provided in the contract between the vendor and the government entity, and
- (d) In all respects is proprietary data belonging solely to NewTek.

For units of the Department of Defense (DoD), this Software is sold only with "Restricted Rights" as that term is defined in the DoD Supplement to the Federal Acquisition Regulations, 52.227-7013 (c) (1) (ii).

Use, duplication or disclosure is subject to restrictions as set forth in subdivision (c) (1) (ii) of the Rights in Technical Data and Computer Software clause at 52.227-7013. Manufacturer: NewTek, 5131 Beckwith Blvd., San Antonio, TX 78249.

If this Software was acquired under a GSA Schedule, the US Government has agreed to refrain from changing or removing any insignia or lettering from the software or the accompanying written materials that are provided or from producing copies of manuals or disks (except one copy for backup purposes) and:

- (e) Title to and ownership of this Software and documentation and any reproductions thereof shall remain with NewTek,
- (f) Use of this Software and documentation shall be limited to the facility for which it is required, and,

(g) If use of the Software is discontinued to the installation specified in the purchase/delivery order and the US Government desires to use it at another location, it may do so by giving prior written notice to NewTek, specifying the type of computer and new location site. US Governmental personnel using this Software, other than under a DoD contract or GSA Schedule, are hereby on notice that use of this Software is subject to restrictions which are the same as or similar to those specified.

Hardware Limited Warranty

Warning, this equipment has been certified to comply with the limits for a Class B computing device, pursuant to Part 15 of the FCC Rules. Only peripherals (computer input/output devices, terminals, printers, etc.) certified to comply with the Class B limits may be attached to this computer when this computer is operated in a residential environment. Operation with non-certified peripherals is likely to result in interference to radio and TV reception.

Instructions to User

This equipment has been tested and found to comply with the limits for Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antennae
- Increase the separation between the equipment and the receiver
- Connect the equipment into an outlet on a circuit different from that which the receiver is connected
- Consult the dealer or an experienced radio-TV technician for help

Note: Changes or modifications not expressly approved by the party responsible for compliance could void the user's right to operate this equipment.

Peripherals used in conjunction with this equipment must be connected via shielded interface cables. Use of unshielded interface cables may result in interference to radio and TV reception, and may void the user's right to operate this equipment.

Limited Warranty

NewTek's Obligation to the Purchaser

NewTek warrants that for a period of one year from the date of your original purchase of our computer/video product, it shall be free from defects in material and workmanship. This written warranty extends to the original purchaser only.

If a defect is determined to be covered by this warranty as determined by NewTek, NewTek will correct it, and may do so using new or remanufactured components.

NewTek's Liability and Limitations

NewTek will not be liable to you or anyone else for any liability, loss or damage for inconvenience or interruption of service, loss of business, data or anticipatory profits, or consequential, incidental or punitive damages resulting from the use (or operation) of any of the products purchased by you. NewTek's liability is limited solely to the repair or replacement of the defective product.

NewTek is under no obligation or responsibility to enhance or update the product you have purchased.

To Obtain Warranty Service

To obtain free repair under this warranty, you must contact NewTek Technical Support for confirmation, receive a Returned Materials Authorization (RMA), and deliver the product along with proof of ownership (such as the original invoice, or a photocopy) to NewTek. You must also pay for any costs associated with the delivery to and from our service center.

What This Warranty Does Not Cover

This warranty does not cover damage or malfunctions resulting from improper handling, accident, misuse, abuse, neglect, electrical surges, failure of electrical power, use with other products not manufactured by NewTek, installation or removal charges or damages, damage while in transit for repair, repair attempted by any unauthorized person or agency, or any other reason not due to defects in materials and workmanship. This warranty is also void if the serial number has been altered, defaced, or removed.

NewTek's Legal Disclaimers

The above warranty is exclusive and in lieu of all other warranties, express or implied (other than those warranties implied by state law). All applicable state statutory implied warranties, including, but not limited to implied warranties of merchantability or fitness for a particular purpose, shall be limited to a period of one year from the date of your original purchase. No warranties, either express or implied, will apply after this period.

Some states do not allow limitations on how long an implied warranty lasts, or the exclusion of warranties

or of incidental or consequential damages, so the above limitations or exclusions may not apply to you. Any term of this warranty that is prohibited by applicable law shall not apply. This warranty gives you specific legal rights, and you may also have other rights which vary from state to state.

Credits

Software Engineers Andrew Cross, Pat Brouillette, Rick Pingry, James Killian
Jamie Finch, Kirk Morger, Gareth Shikles, Masaaki Konno
John Lucas

Hardware Engineers Kevin Rouviere, Winston Ninh, Michelle Wah, Dale Whitt

Interface Design: Argon Hennley, Michael "Aussie" Holten

Testing Jeremy Wiseman, Greg Roadruck, Nick Lucio

Product Management Paul Lara

Content and DVEs, Project Management for CG Billy Pecora

Software Installer Kris Debolt

Documentation Stephanie Barton

Special thanks to Tim Jenison for endless advice, guidance and the vision of what a Toaster should toast. Thanks for the Oreo supply. To the LightWave 3D and Aura development teams for their help in making this a great product. Brian Jansen: For tireless bug reporting, testing and finding the most obscure video issues! Harlan Hill: For constant wackiness. Paul Goldberg: For the very special video tapes he sent in to spear on engineering. All of the companies that make ridiculously expensive editing systems: For leaving so much room for us. All of our Beta Testers: For putting their lives on hold and focusing on the future of video. All of our loyal Toaster/Flyer owners: for loving what NewTek has done and for keeping their eye on the light at the end of the tunnel. Adam Doubleday: for helping keep the Spirit(s) flowing. Patty Whisenhunt and @mic. Dexter Welton for his attention to detail with the manual. And Doug Nakakihara for reading every word. :)

Of course many thanks must go to: Nathalie Cross and Calpyso Cross: For putting up with Andrew Cross. Matthew Lara: for being one of the first beta testers of TEd. Spam Lara: for keeping the office free of squirrels. Robin, Remi and Atticus Nations: for putting up with my endless cycle of "honey I'll be home shortly".... three hours later, "honey I'll be home shortly. " Heidi Pingry: for patience and understanding. Richard and Juanita Pingry: for stepping in and helping with responsibilities that were beyond me. Calvin, Justin, Andrew, Simon Pingry: for giving me smiles to look forward to every day. Maximuz Primiz Pecora: just for being the coolest pup in the world. Hershsprung Barton who doesn't listen ever, but deserves a ton of love anyway. And Lee Barton (the best guy on the entire planet).

Table of Contents

CHAPTER ONE: INTRODUCTION AND INSTALLATION .1.1

Video Toaster [2] Features1.1

Uncompressed Video1.3

About the Manual1.3

Manual Organization1.4

Manual Conventions1.5

Attenticons1.5

Text Formatting1.5

System Requirements1.6

System Specifications1.6

Video Storage Requirements1.7

Dedicated Drives1.8

Audio Drive Requirements1.9

Graceful Scaling of Performance1.10

Hardware Installation:Video Toaster Card1.10

PC Monitor Refresh Rate1.12

To Verify Monitor Refresh Rate1.12

Software Installation:Video Toaster [2]1.12

CHAPTER TWO:

VIDEO TOASTER CARD AND BREAKOUT BOX2.1

Video Toaster Card Input/Output2.1

Connections2.1

SX-8 Breakout Box2.3

Hardware Breakout Box2.3

Computer Connections2.6

Daughter Card2.8

Video 101: Common Formats2.8

To install the daughter card2.9

Virtual Breakout Box	2.11
Breakout Box Context Menu	2.12
Video 101: Digital Active Area	2.12
Inputs and Outputs	2.13
To select a Y/C input	2.14
To select a component input	2.14
Component	2.14
Y/C	2.15
Possible Video Combinations	2.17
Genlock	2.17
Alpha	2.18
Audio	2.18
VTR	2.21
Serial Digital Interface	2.22
SDI Card	2.22
To capture SDI input	2.22
Video 101: SDI Devices and Inputs	2.23
Task: SX-8 Breakout Box	2.24
Add the Breakout Box to the Video Toaster Card	2.24
Add Composite Video to the Breakout Box	2.24
Add S-video to the Breakout Box	2.24
Add Component Video to the Breakout Box	2.25
Add a Microphone to the Breakout Box	2.25
Add Unbalanced Audio to the Breakout Box	2.26
Switch without the Switcher	2.28
Installing the SDI card	2.28
CHAPTER THREE: VIDEO TOASTER [2] INTERFACE	3.1
Video Toaster Desktop	3.1
Starting Video Toaster [2]	3.2
Main Menu	3.2
Exiting Video Toaster [2]	3.3

Minimize, Maximize, and Toggle	3.3
Panels and Skins	3.4
Tinting Panels	3.5
To tint a panel	3.5
Tinting the Desktop	3.5
To tint the Video Toaster desktop	3.6
To remove the tint	3.6
Closing Panels	3.6
Context Menus	3.6
Loading and Saving	3.7
Hold and Restore	3.7
Panel States	3.7
Organization and Features	3.8
Moving Panels	3.8
Stacking and Stretching Panels	3.8
Control Hints	3.8
Scrollbars and Scrolling Action	3.8
Buttons, Tags, and Abbreviations	3.9
Multiple Desktops	3.9
Shortcuts for Multiple Desktops	3.10
Multiple User Configurations	3.11
To save a configuration for the Video Toaster desktop	3.11
Assignments/Shortcuts	3.11
Global Shortcuts	3.11
Preferences and Configurations	3.13
System Preferences	3.13
DDR/Editor Preferences	3.15
Other Modules	3.17
SX-8 BoB Preferences	3.18

File Formats	3.19
Input and Output	3.20
Task: Get Acquainted with the Interface	3.21
Video Toaster Desktop	3.21
Set up the Preferences Panel	3.22
CHAPTER FOUR: VIDEO AND AUDIO CAPTURE	4.1
Capture Panel	4.2
Capture Options	4.2
Volume Units Meter	4.3
Choosing Compression Formats	4.4
Video Codecs	4.4
Video 101: Video Codecs:	4.4
Audio Codecs	4.7
Selecting Resolutions	4.11
Input and Output	4.12
Video and Audio	4.12
Time Limits	4.12
Record	4.14
Audio Level	4.14
Deck Controls	4.15
Task: Capture Panel	4.16
Capture Uncompressed Video Directly from Source	4.16
Capture and Chop	4.18
Capture and Reset	4.18
Capture and T.Lapse	4.19
CHAPTER FIVE: TOASTERVISION MONITOR	5.1
ToasterVision	5.1
ToasterVision Controls	5.2
Underscan	5.3
Viewing Options for ToasterVision	5.3

ToasterVision Context Menu	5.4
Skins for ToasterVision	5.7
Fielding	5.8
Task: ToasterVision	5.9
ToasterVision and Panels without the Switcher	5.9
ToasterVision with the Switcher	5.10
CHAPTER SIX: FILE BIN	6.1
General Usage	6.2
Options	6.2
Navigating and Editing	6.2
Hotlist	6.3
To add a folder or directory to the Hotlist	6.3
To give an Alias to a Hotlist item	6.4
To remove a folder from the Hotlist	6.4
New Folder	6.4
File Bin Context Menu	6.5
File Properties	6.5
To access File Properties	6.5
To rename a folder	6.6
To color-code a file	6.6
Alias	6.6
To give your file an Alias	6.6
Render from the File Bin	6.7
View Modes	6.7
Animated Icons	6.8
Default Icons	6.9
Play from the File Bin	6.9
File Bin Shortcuts	6.9
Task: File Bin Interface	6.10
Browse to Files	6.10

Move Files, Create a New Folder, and Hotlist	6.10
CHAPTER SEVEN: SWITCHER	7.1
Interface	7.2
Main Bus	7.3
Preview Bus	7.3
Key Bus	7.4
To use the Key bus and the Keyer	7.5
To use the Key bus and the Keyer with Unlock Key	7.5
Adding Sources to the Switcher	7.6
Black Source	7.7
Bus Dots	7.7
Deleting Sources	7.7
To delete sources	7.7
Selecting Multiple Sources	7.8
To select multiple sources	7.8
T-bar and Transitions	7.9
Dissolve	7.9
T-bar Options	7.9
Auto and S-M-F	7.10
Take	7.11
To use the Switcher	7.11
DSK	7.12
DSK Sources	7.12
To bring up the DSK	7.13
To fade DSK onto video	7.13
To fade and create a semi-transparent DSK	7.13
Effects Bus	7.14
To load DVEs into the Effects bus	7.14
Using DVEs with the Switcher	7.15
To use a DVE with Switcher controls	7.15
To use a DVE with the right mouse button	7.16

Switcher Context Menu	7.17
Inputs Context Menu	7.17
Panel Context Menu	7.18
Video Toaster Panels and the Switcher	7.18
Using Multiple Cameras	7.20
Live Switching	7.20
Switcher and Live Internet Streaming	7.20
Task: Switcher	7.21
Set up Capture from the Switcher	7.21
Add and Organize Inputs on the Switcher	7.22
Switch with Auto, T-bar, and Take	7.23
Switching and DSK	7.23
Switching and DVEs	7.24
Ending with CG	7.25
CHAPTER EIGHT: TOASTEREDIT	8.1
ToasterEdit Interface	8.1
ToasterEdit File Bin	8.3
Working with ToasterEdit	8.5
To save a ToasterEdit project	8.5
To open a recent ToasterEdit project	8.5
File Button	8.6
Common Action Buttons	8.7
To load an undo-redo stack	8.8
VTR Controls	8.9
Edit Button	8.9
Trans Options	8.10
Rewind and Fast Forward	8.10
Shuttle and Jog	8.10
To playback a slow motion preview	8.10
Scrubbing Playback	8.11

VTR Options and Modes	.8.11
Track	.8.11
Looping	.8.12
Timecode	.8.12
Compatible Formats	.8.12
ToasterEdit Croutons	.8.13
ToasterEdit and DVEs	.8.14
ToasterEdit Storyboard	.8.16
Moving around the Storyboard	.8.16
To move Storyboard croutons	.8.16
Storyboard Croutons	.8.17
To color-code croutons	.8.18
Storyboard Croutons and In/Out Points	.8.18
To preview the in and out points for a Storyboard crouton	.8.18
To change in and out points for a Storyboard crouton	.8.18
To adjust both in and out frames (slip and slide):	.8.19
To adjust only audio (for crouton with audio and video)	.8.19
To perform slip and slide on audio only	.8.19
Storyboard and DVEs	.8.19
ToasterEdit Timeline	.8.19
Timeline Time Bar	.8.19
To pan the Time Bar	.8.20
To zoom in and out of the Time Bar	.8.20
Timeline Layout	.8.20
Edit Line	.8.21
Timeline Croutons	.8.21
To drag in and out points	.8.23
To change length	.8.23
To make a multi-cam style edit	.8.24
Edit Properties panel	.8.24
In and Out Points	.8.25

Adjusting In and Out Points	8.26
To adjust of in and out points graphically	8.26
To adjust in and out points numerically	8.26
Ripple Mode	8.27
General Options	8.28
Edit Streams	8.30
To pan an image from left to right	8.32
To zoom out of an image	8.32
To zoom out as you pan	8.32
To pan a zoomed image	8.32
To pan and hold an image	8.32
To zoom in, hold, then pan the image	8.32
To use Chroma Key in ToasterEdit	8.36
To add keyed video to background video in ToasterEdit	8.36
To size and position video	8.38
To overlay the positioned video	8.40
Keyframing	8.40
To set keyframes in ToasterEdit	8.40
To set keyframes for position	8.41
To copy keyframes	8.42
Audio in ToasterEdit	8.43
Audio Edit Properties Panel	8.44
To fade audio in and out	8.45
To keyframe audio volume	8.45
Video 101: Sweetening	8.45
Layering Audio	8.46
SubProjects	8.46
To create a subproject	8.46
SubProjects in the Storyboard	8.46
To expand a subproject	8.46
To collapse a subproject,	8.47
To drill into a subproject	8.47

SubProjects in the Timeline	8.48
Context Menu	8.48
Inherit	8.49
To inherit settings from a crouton	8.49
To inherit settings from a crouton (keyboard shortcut)	8.49
Overlay	8.49
To overlay a crouton	8.49
To add an overlay from the context menu	8.50
Into Sub-Project	8.50
To paste into a subproject	8.50
Razor at Edit Line	8.50
To chop a crouton	8.50
To create a single-frame crouton	8.51
Remove Inactive Areas	8.52
Render Options	8.53
Codecs and Resolution	8.54
Render Name and Location	8.54
Render Streams	8.54
Render Direction and Speed	8.54
Render from the File Bin	8.55
Task: ToasterEdit	8.56
Preliminaries	8.56
Move and Make a Subproject on the Storyboard	8.56
Work on the Timeline	8.57
Luma Key and Position in the Edit Properties Panel	8.58
Tweak the Audio	8.60
Finish and Play	8.61
CHAPTER NINE: AUDIO MIXER	9.1
Input and Output	9.2
Microphone/XLR Balanced Input	9.2
RCA Stereo Input on the SX-8	9.4

Video 101: Balanced and Unbalanced Input	9.4
Patch Points for Audio Files	9.5
To patch a computer-generated input to the audio mixer	9.5
Audio Mixer Channels	9.6
Volume Unit Meters	9.6
Channel Controls	9.7
Volume	9.9
Aux Send and Return	9.10
Toaster In	9.11
Live and Preview	9.11
Presets	9.12
To create a Preset	9.12
To recall a Preset	9.12
Preset Speed	9.13
To apply Speed to Presets	9.13
Switcher Options	9.13
To Cue a Preset	9.13
Toaster Out and the Master Signal	9.14
PA Mix and SX-8 Live	9.14
Working with Equipment	9.15
Task: Audio Mixer	9.16
Set Up the Audio Mixer and Switcher	9.16
Audio Mixer Presets	9.16
Audio Mixer and the Switcher	9.17
Finish the Program	9.18
CHAPTER TEN: DIGITAL DISK RECORDER	10.1
Working with the DDR	10.2
Playlist	10.2
To add multiple clips to the DDR	10.3
Deck Controls	10.3
Shuttle and Jog	10.4

Recording	10.4
Cue	10.5
To cue the DDR	10.5
DDR and Audio	10.6
To adjust the volume of a clip in the DDR	10.6
To control the overall volume of the DDR	10.6
Trimming Clips	10.6
Trimming DDR Clips	10.7
To graphically mark your in and out points in the DDR	10.7
Trimming Audio Clips	10.8
Position Indicators	10.8
Moving and Cloning Clips	10.8
Deleting Video Clips	10.9
Closing the DDR	10.9
Video 101: Timecode	10.9
DDR Play Modes	10.10
Playlist Mode	10.10
Loop Play Mode	10.11
Timecode Mode	10.11
Timecode Display	10.11
DDR Context Menu	10.12
DDR and ToasterVision	10.12
DDR and Switcher	10.12
DDR and ToasterEdit	10.14
Task: Digital Disk Recorder	10.15
Add Clips	10.15
Trim Clips	10.15
Cue and the Switcher	10.15
Record a Still Playlist	10.16

CHAPTER ELEVEN: EXTERNAL CONTROL11.1

Interface11.1

Deck Controls11.2

Timecode11.3

External Control Context Menu11.3

Task: External Control11.4

Capture from the External Control11.4

Record with the External Control11.4

CHAPTER TWELVE: DIGITAL VIDEO EFFECTS12.1

Digital Video Effects12.1

Transitions and DVEs12.2

Locating the DVEs12.2

DVEs on the Switcher12.3

To finely adjust DVE speed12.4

DVEs in ToasterEdit12.6

DVE Descriptions12.7

CHAPTER THIRTEEN: COLOR PICKER13.1

Working with the Color Picker13.1

Palette of Color Swatches13.2

Color Channels13.2

Pick Color/Eyedropper13.4

Accessing Your Colors13.5

Video 101: What is color?13.5

Closing the Color Picker13.6

Tinting with the Color Picker13.6

Task: Color Picker13.7

Create a Custom Color Swatch13.7

Right-click to Create a Custom Color13.7

Enter Values to Create a Custom Color13.7

Select a Swatch and Create a Custom Color13.7

Create a Swatch with Transparency	13.8
Range of Colors in the Palette	13.8
Range of Colors from Dark to Light	13.8
Range Between Two Colors	13.8

CHAPTER FOURTEEN: CHARACTER GENERATOR ...14.1

Interface14.2

Safe Area for CG	14.2
TVision and CG	14.3
General Buttons on the CG	14.4
Saving and Exiting the CG	14.4

Tools for CG14.5

Text in CG	14.5
To create text	14.6
Boxes in CG	14.7
To create a box	14.7
To adjust a box after you create it	14.7
Polygons and Splines in CG	14.8
To use the Polygon tool	14.8
To adjust a Polygon after you create it	14.8
Lines in CG	14.9
To create a line	14.9
Circles, Pies, and Arcs in CG	14.9
To create a circle	14.10
To adjust a circle after you create it	14.10
To create a partial circle	14.10
Images in CG	14.11
To load an image	14.11

Transforming CG Elements14.12

Move, Scale, and Rotate with Modify	14.12
To move an item	14.12
To scale an item	14.12

To rotate an item	14.13
Italics for CG Text	14.13
To adjust italics	14.13
Borders and Shadows in CG	14.14
To adjust the border	14.14
To adjust the Shadow	14.14
Motion for CG	14.14
Direction	14.15
Behavior	14.15
Speed Control for CG	14.16
Output for CG	14.16
Cueing CG for the Switcher	14.16
Go	14.16
Program Out	14.16
Pages and Layout in CG	14.17
Layout Tab	14.17
Pages Tab	14.19
CG Properties	14.21
Previews of CG Styles	14.21
Text Properties	14.21
Lock	14.23
Border Properties	14.23
Shadow Properties	14.24
Fill Properties	14.25
Arc/Line Properties	14.27
CG Player	14.28
Task: Character Generator	14.30
Create a Title Page	14.30
Create a Lower Third	14.37
Crawling the Lower Third on Screen	14.41
Create a Scroll	14.42

Create a Page Build	14.45
---------------------------	-------

CHAPTER FIFTEEN: BACKGROUND GENERATOR15.1

Working with the Background Generator15.2

To create a background color	15.2
To create a semi-transparent background color	15.2
Solid Background	15.2
Horizontal Gradient	15.3
Vertical Gradient	15.4
4 Corner Gradient	15.4
Using the Background Generator	15.5
Tinting the BG	15.5

Task: Background Generator15.6

Task: Make a Background	15.6
Task: BG on the Switcher	15.6

CHAPTER SIXTEEN: CHROMA AND LUMA KEYING . .16.1

Luma Keying16.1

Chroma Keying16.2

Pacifica RK95 Keyer Interface16.2

Luma White and Luma Black	16.2
Linear Keying	16.3
Linear Luma	16.3
Chroma Key	16.4
To pick a color with the eyedropper tool	16.5
To pick a color from the Color Picker panel	16.5
Tolerance	16.5
Smooth	16.6
Video 101: Blue Screens	16.6
To use Smooth and Tolerance for the best results in keying . . .	16.7
Keying and CG	16.7
Context Menu	16.7
Presets	16.7

To store a preset	16.7
To recall a preset	16.7
Cross Keyer	16.8
Context Menu and Presets	16.9
Working with the Cross Keyer	16.9
Tolerance	16.10
Smooth	16.10
Task: Keying	16.11
Pacifica Keyer	16.11
Cross Keyer	16.12
CHAPTER SEVENTEEN: TOASTERSCOPE	17.1
Monitoring a Signal	17.2
Interface	17.3
Refresh	17.3
Waveform	17.3
Video 101: How to Read the Waveform Monitor	17.6
Vectorscope	17.7
Video 101: How to Read the Vectorscope	17.7
Video 101: Blanking and Burst	17.8
CHAPTER EIGHTEEN: PROCESSING AMPLIFIER	18.1
Understanding the Processing Amplifier	18.2
Interface	18.2
Brightness	18.3
Contrast	18.4
Hue	18.4
Saturation	18.4
U Offset	18.5
V Offset	18.5
U Gain	18.6
V Gain	18.6

Bypass	18.6
On/Off	18.7
Track Preview	18.7
Context Menu	18.7
To store a preset	18.9
To recall a preset	18.9
To save a Proc Amp setting	18.9
Processing Amplifier and ToasterScope	18.12
Color Bars Test Signal	18.12
To correct chrominance phase	18.15
To correct chrominance gain	18.15
Task: Processing Amplifier	18.16
Proc Amp and Color Bars	18.16
Proc Amp and Tinted People	18.17
GLOSSARY	19.1
APPENDIX A: KEYBOARD SHORTCUTS	ApA.1
General Shortcuts	ApA.1
Selection Shortcuts	ApA.2
Video Toaster desktop shortcuts	ApA.2
File Bin Shortcuts	ApA.3
Switcher Shortcuts	ApA.3
Black Source	ApA.3
Program Bus	ApA.3
Preview Bus	ApA.3
Key Bus	ApA.4
LockKey, Reverse, and Tbar	ApA.4
DSK	ApA.4
ToasterEdit Shortcuts	ApA.4
Storyboard	ApA.4
Timeline	ApA.5

APPENDIX B: STREAMING MEDIAApB.I

Video Toaster and the WebApB.I

EncodingApB.1

Streaming and Video ToasterApB.3

Getting Your Video on the WebApB.5

Getting Your Files on the ServerApB.5

Preparing for EncodingApB.6

Tips for Video on the WebApB.7

APPENDIX C: DVE DESCRIPTIONSApD.I

DVE Organization and ConventionsApD.I

The Numeric Codes:ApD.2

Toaster Digital Video Effects DescriptionsApD.9

